

# Art. nr 121426 Seal for Rapid SL/Solido Leakage box

C900125

RSK xx VVS xx NRF xx LVI



Systemgodkänd för följande tätskikt. Ladda ned detaljerade instruktioner från respektive tillverkare.

System approved for the following waterproof layers. Download detailed instructions from respective producer.

Ardex 7+8	Finja	Midun
Bostik Pro	FF System Folie	Mira Vapourmat 100
Bostik Universal	GK Hero	PCI VG2014
Casco	Hey'di	Schönox
CC Höganäs	Kiilto Kerasafe +	Sopro AEB 815
Centro TM	LIP System 27	Weber Tec
Ecodur	MAPEI WP90/WP200	Zebra

Börja med att montera fixturen enligt anvisning från GROHE, se [GROHE.se/no/fi/dk](http://GROHE.se/no/fi/dk)  
 Start by mounting the WC fixture according to the instructions from GROHE, visit [GROHE.se/no/fi/dk](http://GROHE.se/no/fi/dk)



<p>1. Slipa av insidan av plastboxen med fint sandpapper där manschetten skall limmas. (Se röd pil)</p> <p>2. Torka bort slipdammet med T-Röd.</p>	<p>3. Applicera tätskiktstillverkarens lim på insidan av plastboxen.</p> <p>4. Stryk ut limmet med fintandad limspridare Elit eller likvärdig.</p>	<p>5. Applicera tätskiktstillverkarens lim på väggytan som manschetten täcker. (Använd roller eller pensel enligt tätskiktstillverkarens instruktioner)</p>
<p>1. Sand the inside of the plastic box with fine sandpaper where the cuff is to be glued (see red arrow).</p> <p>2. Wipe off the sanding dust with T-Red / Denatured alcohol.</p>	<p>3. Apply your selected waterproof layer's glue to the inside of the plastic box.</p> <p>4. Spread the glue with a fine-toothed glue spreader Elite or equivalent.</p>	<p>5. Apply the selected waterproof layer's glue to the wall surface covered by the cuff. (Use roller or brush according to the producer of your waterproof layer's instructions).</p>



<p>6. Tryck noga fast manschetten mot insidan av plastboxen med en liten plastspackel. Säkerställ så att inga veck / luftblåsor uppstår.</p> <p>7. Tryck noga fast manschetten mot väggunderlaget med plastspackeln. Var noga med att inga veck eller luftblåsor uppstår.</p>	<p>8. Applicera tätskiktstillverkarens lim på manschetten.</p> <p>9. Applicera lim på vägg enligt tätskiktets instruktioner en våd i taget.</p> <p>10. Montera Folie i det våta membranet och överlappa manschetten med minst 5 cm.</p>	<p>11. Förslut skarven mellan folien och manschetten med tillverkarens lim.</p> <p>12. Förslut även skarven mellan manschetten och plastbaljan med tätskiktstillverkarens lim. 2 strykningar.</p>
<p>6. Press the cuff firmly against the inside of the plastic box with a small plastic putty knife. Make sure that there are no creases or air bubbles.</p> <p>7. Carefully press the cuff against the wall base with the plastic putty knife. Make sure there are no creases or air bubbles.</p>	<p>8. Apply your selected waterproof layer's glue to the cuff.</p> <p>9. Apply glue to the wall according to the producer of your waterproof layer's instructions one breadth at a time.</p> <p>10. Install foil in the wet membrane and overlap the cuff by at least 5 cm.</p>	<p>11. Seal the joint between the foil and the cuff with the producer's glue.</p> <p>12. Also seal the joint between the cuff and the plastic tub with the sealant manufacturer's glue. 2 covering turns.</p>

OBS. Vägg-materialet skall uppfylla gällande branschregler  
 Note. the wall material must comply with current industry regulations.

För mer information, se [www.leakagebox.com](http://www.leakagebox.com) och respektive tätskiktstillverkarens websida  
 For more information, visit [www.leakagebox.com](http://www.leakagebox.com) and respective producer of the waterproof layer's website.