


# Panasonic®

## Quick Menu Guide (Mono bloc) Air-to-Water Heatpump



Model No.

Mono bloc Unit


WH-MXC09J3E5-1

WH-MXC12J6E5-1

WH-MXC09J3E8-1

WH-MXC12J9E8-1

WH-MXC16J9E8-1



<b>Quick Menu Guide</b> (Mono bloc) Air-to-Water Heatpump	2-7	English
<b>Hurtig menuvejledning</b> (Monobloc) Luft-til-vand-varmepumpe	8-13	Dansk
<b>Guía del menú rápido</b> Bomba de calor de aire a agua (Mono bloc)	14-19	Español
<b>Guida rapida dei menu</b> Pompa di calore Aria-acqua (Mono bloc)	20-25	Italiano
<b>Handleiding snelmenu</b> (Mono bloc) Air-to-Water Warmtepomp	26-31	Nederlands
<b>Przewodnik po skróconym menu</b> (Monoblok) pompa ciepła powietrze-woda	32-37	Polski
<b>Οδηγός Σύντομου Μενού</b> Αντλία Θερμότητας Αέρος-Νερού (Monoblock)	38-43	Ελληνικά
<b>Průvodce Rychlá nabídka</b> Teplné čerpadlo vzduch-voda (Monoblok)	44-49	Český
<b>Guide du menu rapide</b> Pompe à chaleur air-eau (Mono bloc)	50-55	Français
<b>Schnellmenü-Anleitung</b> (Kompaktgerät) Luft/Wasser-Wärmepumpe	56-61	Deutsch
<b>Hızlı Menü Kılavuzu</b> (Monoblok) Hava-Su Isı Pompası	62-67	Türkçe
<b>Snabbmenyguide</b> (Monobloc) Luft-till-Vatten-Värmepump	68-73	Svenska
<b>Hurtigmenyveiledning</b> (Monobloc) Luft-til-vann-varmepumpe	74-79	Norsk
<b>Pikavalikko-opas</b> (Monobloc) Ilmavesilämpöpumppu	80-85	Suomi
<b>Útmutató a gyorsmenühöz</b> (Monoblokk) Levegő-víz hőszivattyú	86-91	Magyar
<b>Hitri vodnik meniju</b> (Monoblok) Toplotna črpalka zrak-voda	92-97	Slovenščina
<b>Vodič za Brzi izbornik</b> (Monoblok) Toplinska pumpa zrak-voda	98-103	Hrvatski
<b>Sparčiojo meniu vadovas</b> („Mono bloc“) Šildymo siurblys oras-vanduo	104-109	Lietuvių




# Before Use

This Quick Guide explains how to use the Quick Menu.


Please read the Operating Instructions thoroughly before using the Quick Menu.

## How to use the Quick Menu

After the initial settings have been completed, you can select a quick menu from the following options and edit the setting.



① Press  .



② Use     to select menu.

③ Press  to turn on/off the select menu.

### Quick Menu



Force DHW



Powerful



Quiet



Force Heater



Weekly Timer



Force Defrost



Error Reset



R/C Lock

 Select

 ON/OFF

Select each setting and confirm the setting according to the instructions displayed at the bottom of the screen. (The icons refer to each selection key.)

To return to the Main Screen,

Press  or  .

# How to use the Quick Menu

## Notes on operation icon


Example:



• Operation icon indicate with “.....” = OFF



• Operation icon indicate with “———” = ON



## Force DHW

Select this icon to turn the Tank DHW on or off.

Press  to confirm your selection.




• Force DHW is turned off.



• Force DHW is turned on.

### ■ Note:


- Force DHW is disabled when Force Heater is turned on.
- When Force DHW is turned off, operation & mode should change back to the previous memorized status.



## Powerful

Select this icon to operate the heating/cooling system powerfully.

Press  to confirm your selection.

(The powerful operation starts approximately 1 minute after  is pressed.)



• Powerful mode is set off.



• The Powerful mode operates for 30 minutes.



• The Powerful mode operates for 60 minutes.




• The Powerful mode operates for 90 minutes.

### ■ Note:

- Powerful is disabled when operation is turned OFF.

# How to use the Quick Menu




Quiet

Select this icon to operate quietly.

Press to confirm your selection.

(The quiet operation starts approximately 1 minute after is pressed.)



Do you want to edit  
Quiet timer pattern?

Yes No

Pattern	Time	Level
1	6:00 am	2
2	8:00 pm	1
3	10:00 pm	0

Edit

Delete

12:00 pm



Set time is overlapped!

[>]Close

Select "Yes".

• Select "Yes" using buttons.

Select pattern "1" ~ "6".

Select "Edit".


• If you select "Delete", the timer setting of the selected pattern will be deleted.

Set the hour and minutes.

Select the level of Quiet.

■ **Note:**


• If the time overlaps with another pattern, "Set time is overlapped!" will appear on the screen.




## Force Heater

Select to force the Heater on.

Press  to confirm your selection.

(The Force Heater mode starts approximately 1 minute after  is pressed.)




### ■ Note:

- Force Heater is disabled whenever operation is already on and 'Disabled due to operation ON!' will be displayed.

Disabled due to  
operation ON!

Close


# How to use the Quick Menu



## Weekly Timer

Select this icon to delete (cancel) or change the pre-set Weekly Timer.

Press to confirm your selection.



Do you want to edit Weekly timer pattern?

Yes No

Select "Yes".

• If you select "No", the screen will return to the Main Screen.

Timer setup  
Timer copy

• Timer setup: Select Timer setup to edit the Weekly Timer.  
• Timer copy: Select to copy a timer setting.

Sun	Mon	Tue	Wed	Thu	Fri	Sat
—	✓	✓	✓	✓	✓	—

[Example of a Timer setup]

Select the day(s) which you wish to edit using ▲ ▼ buttons.

All 6 patterns are not set!  
Do you want to edit?

Yes No

If all 6 patterns are not preset, this screen will be displayed.

Sun	Mon	Tue	Wed	Thu	Fri	Sat
1. 12:00am ON   25/20°C 40°C	2. 2:00am ON   25/25°C 40°C	3. 4:00am ON   30/20°C 40°C				
①	②	③	④	⑤	⑥	

① Select pattern "1" ~ "6".

② Set the hour and minutes of the Timer.

③ Select ON/OFF of the Timer.

④ Select the operation mode.



• Select mode using ▲ ▼ buttons.


⑤ Set the temperature for both Zone 1 and 2 (if your system has the 2-Zone setting).

Saturday: Pattern 1: Set Temp		
Zone1	Zone2	
ON 25°C	ON 25°C	45°C

⑥ Set the Tank temperature.

### Note:

- Timer is disabled when Force Heater is turned on or Heat-Cool SW is enabled.
- If you have preset the Weekly Timer on 2 zones, you must repeat the same procedure with Zone 2.



## Force Defrost


Select to defrost the frozen pipes.

Press to confirm your selection.

(When the mode is accepted, below screen will be displayed.)

Request accepted!

]Close



## Error Reset

Select to restore the previous settings when error has occurred.


Press to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)

Request accepted!

]Close

- Make sure all units are turned off before selecting this mode which restores the whole system to the previous settings.



## R/C Lock

Select to lock the Remote Controller.

Press to confirm your selection.

(When the mode has been accepted, below screen will be displayed.)

Do you want to  
lock remote control?

Yes

No

Select "Yes".

(The Main Screen will be locked.)

- If "No" is selected, the screen will return to the Main Screen.

To unlock the Remote Controller

Press any key.

(When the mode has been accepted, below screen will be displayed.)



Enter any 4 digits of number (if the number is correct, the screen will be unlocked).

To reset forgotten password (under operation OFF screen)

Press , and continuously for 5 seconds.

(When the mode has been accepted, below screen will be displayed.)

Reset password

Reset

Select "Reset".

1.Password is reset to 0000  
2.Remote control is unlocked

(The screen will be off after 3 seconds.)