




DTV200S

DTV200S

Mått / Dimensions / Mål / Dimensions / Abmessungen / Dimensiones / Afmetingen / Dimensioni / Wymiary / основные размеры




Inställningar / Settings / Innstillinger / Réglages / Einstellungen / Ajustes / Instellingen / Impost / Nastawy / Установка перемычек


PA3500/PA4200/ADCS/ACC		
Fan step	ΔP [Pa]	Performance reduction
5	240	10-20%
4	200	
3	150	
2	110	
1	70	

DTV200S

Installation / Installation / Installasjon / Raccordement / Installation / Instalación /
 Installatie / Installazione / Podłączenie / Подключения



DTV200S + SIRe



Main office

Frico AB
Box 102
SE-433 22 Partille
Sweden

Tel: +46 31 336 86 00
Fax: +46 31 26 28 25
mailbox@frico.se
www.frico.se

**For latest updated information and information
about your local contact: www.frico.se**