



SV: Åtgärd för själv-vandrande temperaturvred  
EN: Measure for self-moving temperature knobs

---

SV: Demontering  
EN: Disassembly



SV: Montering  
EN: Montering



4 For remounting, see disassembly

---

5 **Calibration of temperature:** Remove the cover and dismantle the temperature control knob. Turn the spindle clockwise for cooler water and anti-clockwise for warmer water. When the correct water temperature has been reached (approx. 38°C), connect the temperature control knob so that the button is aligned with the marking on the mixer body.

**NOTE!** The stop lug for the scalding protection ring should be aligned with the marking on the mixer body.

For more information, see the respective instruction for your thermostat.