



PM-362 L=362mm x 1	P2 ø 18 x 2					
G71 x 1	S1 ST6x60 x 4	S2 UX8 x 4	P0 ø 5 x 20	K1 M4x22 x 7	H-800 L=800mm x 1	H-160 x 2


01.




02.




03.




04.




05.




06.



07.





Justering av låda
 - Öppna låsskruv
 - Justera 08.3 & 08.4
 - Stäng låsskruv

